



## **Installation instructions**

## **MSK FDO**

## Installation

IQ Sensor:





Insert Sensor <u>until stop</u>, then tighten coupling ring

Do not lubricate the O-rings in the adapter!

IQ SW Sensor:







## **Technical data**

**Length:** approx. 93 mm with adapter

59.5 mm without adapter

1.

**Diameter:** 59.5 mm

Material: Plastic parts: POM

O-rings: EPDM and FPM

ba76016e01 01/2012