



a xylem brand

Installation instructions

MSK FDO® CS

Cleaning set for FDO® 700 IQ SW



Set content

Pos.	Description	Material
1	Screwed connection	Nickel-plated brass
2	Adaptor	POM
3	Hose clamp	V4A stainless steel
4	Fabric-reinforced compressed air hose	PVC
5	Compressed air hose	PU
6	Elbow joint	POM
7	Nozzle	V4A stainless steel 1.4571

Installation

- Connect the open end of the fabric reinforced compressed air hose to the compressed air source (z. B. MIQ/CHV PLUS)
- Screw the elbow joint to the MSK FDO® protective hood