ProDSS Driver Installation on Windows 10 Operating Systems

- 1. Turn the instrument on and connect it to the PC with the included USB cable.
- 2. Open **Device Manager** by typing "Device Manager" in the search box on the Windows 10 taskbar (Figure 1).




Figure 1 Windows 10 search box

3. Under Ports, right click on USB Serial Device and select Update Driver Software (Figure 2).




Figure 2 Device Manager Windows 10

- 4. Click Browse my computer for driver software.
- 5. Click Browse, then navigate to the file location: C:\Program Files (x86)\YSI\KorDSS for 64 bit systems (Figure 3) or C:\Program Files\YSI\KorDSS for 32 bit systems. Click Next.




Figure 3 Driver location Windows 10

6. After successful driver installation, open KorDSS and follow steps in the KorDSS Startup Wizard if starting KorDSS for the first time.

For additional information or assistance, please contact YSI Technical Support by calling 800-897-4151 (+1 937-767-7241) or by sending an email to info@ysi.com.

