



a xylem brand

## Parts list

Item	Description	Quantity
1	Clamping device	2
2	Hexagon head bolt M6 x 110	4
3	Nut M6	4
4	Lock washer for M6	4
5	Cap screw M5 x 8	4
6	Shim for M5	4
7	Nut M6	4
8	Lock washer for M6	4

## Assembly


- Pre-assemble each of the four hexagon head bolts (2) with a nut (3) and a lock washer (4) to a clamping device (1).
- Assemble the shed to the preassembled clamping device using the Cap screws (5) and shims (6).
- Position both clamping devices at the pipe and fix them using the four nuts (7) and the four lock washers (8).

## Materials

All parts are made of stainless steel 1.4301.

Operating manual

## Assembly set for tube assembly MR/SD 170



**Parts list**

Item	Description	Quantity
1	Clamping device	2
2	Hexagon head bolt M6 x 110	4
3	Nut M6	4
4	Lock washer for M6	4
5	Cap screw M5 x 8	4
6	Shim for M5	4
7	Nut M6	4
8	Lock washer for M6	4

**Assembly**

- Pre-assemble each of the four hexagon head bolts (2) with a nut (3) and a lock washer (4) to a clamping device (1).
- Assemble the shed to the preassembled clamping device using the Cap screws (5) and shims (6).
- Position both clamping devices at the pipe and fix them using the four nuts (7) and the four lock washers (8).

**Materials**

All parts are made of stainless steel 1.4301.

**Assembly set for tube assembly  
MR/SD 170**

a xylem brand

