



## **Reclaiming the Land for Wetlands**

## Large-scale floodplain restoration project seeks to put nature back in balance

At 7,100 acres, Emiquon Preserve is one of the largest floodplain restoration projects in the United States outside the Florida Everglades. Located within the Upper Mississippi River system, Emiquon was, until very recently, a vast expanse of plowed fields and

rotating crops in the country's farming heartland. Beginning in 2007, The Nature Conservancy (TNC) began to restore Emiquon from agricultural land to floodplain wetlands.

100 years of agriculture, while providing food, has taken its toll on the region's ecosystem. Natural water flow patterns have been disrupted by levees on the Illinois River (a tributary of the Mississippi). A rich and varied floodplain – comprised of co-existing slices of prairie, meadow, marsh, shrubbery, forest, and shallow water pools – has mostly disappeared. And with it the plants, animals, birds, and fish that called this habitat home.

Now, one group is about to undertake a momentous reversal of the past century's practices and return this area to its natural state. "Emiquon is a premiere demonstration site for the Conservancy's work on the Illinois and Mississippi Rivers. Research and management of this large restoration project may ultimately help us guide other floodplain river restoration efforts around the world," notes Maria Lemke, aquatic biologist with TNC.

She and her colleagues are the core team which will guide this renaissance.

To begin with, TNC purchased all 7,100 acres of Emiquon. "We enrolled it in the Wetlands Reserve Program, a federal program that pays landowners to convert farmland back to natural habitat. Our partner in this has been the [USDA's] Natural Resources Conservation Service, which purchased an easement on most of the acres and helped us with the financing," Lemke says.

Next comes the science part. 2006 was the last year that crops were planted in Emiquon. TNC has set up three monitoring stations within the preserve to assess water quality and gather baseline data. The data help TNC monitor its Key Ecological Attributes (KEAs) and will help to measure the conservation progress.

"KEAs are objectives or targets within our restoration plan," ex-

plains Lemke. "They include specific items such as underwater irradiance, water depth, hydrology, and fish reproduction. What this means is, as we try to reintroduce aspects of the original habitat, like submersed and moist soil vegetation, fish, and shorebirds, we are measuring the water quality for key indicators that can tell us if the water will support and promote the growth of these elements."

Monitoring stations are equipped with instruments from YSI Inc., an Ohio based designer and manufacturer of water quality instrumentation. YSI 6600 sondes at the stations measure water depth, temperature, dissolved oxygen, pH, and turbidity. Additionally, a YSI MET suite measures wind speed and direction, solar radiation, and rainfall and a YSI EcoNet Data Acquisition System telemeters all these data, in real-time, back to the researchers and scientists working on this project.

For example, as pumping ceases and water levels rise across the formerly drained farmland, the monitoring stations provide data on water depth.

Maintaining a specific depth allows TNC to reintroduce certain species of vegetation that once thrived in this floodplain. Soon to emerge are new swaths of tallgrass prairie, wet prairie, bottomland forests, and upland trees and shrubs.

Additional data from YSI instruments, including dissolved oxygen and turbidity measurements, will be used by TNC for adaptive management decisions throughout the course of the restoration. Notes Lemke, "By analyzing the real-time data from





Both photos: Thompson Lake. Former farmland adjacent to lake was returned to its natural floodplain habitat and aquatic vegetation re-established.

©2007 YSI Incorporated

+1 937 767 7241

Fax +1 937 767 9353

environmental@ysi.com

www.ysi.com 0907 A558



remote sites, furnished by YSI EcoNet, we can make adaptive decisions regarding our KEAs and biodiversity during the restoration process. This kind of directed management is especially important so that the Emiquon model can be used for restoration of other large floodplain rivers around the world, including the U.S., Africa, Brazil, and China."

EcoNet units have been placed at three sites within Emiquon: 1) the main drainage ditch near a pump station situated next to the river, 2) South Thompson Lake, and 3) North Thompson Lake. Noticeable to many passersby, 600 acres of the historical Thompson Lake bed have been flooded during the first phase of restoration. Lemke explains, "Thompson Lake was formerly a backwater of the Illinois River and was legendary in terms of its productivity and the fish and waterfowl it supported prior to draining and leveeing in the 1920s. Although it has been nearly a century since the lake held water, there are already many aquatic plants and animals that have returned."

Over the course of the restoration of the Emiquon Preserve, Lemke and her fellow researchers at The Nature Conservancy hope to see this rebirth of the ecosystem continue to flourish. Continuous monitoring systems from YSI will be at-hand and online to provide the frequent, critical data they need to test models that predict responses of hydrology, sediment resuspension, and vegetation growth.

"These real-time data are already showing us some interesting patterns and are providing essential information for adaptive management," concludes Lemke. The new-found life within the waters is a convincing sign of their success so far.

Real-time data are available online: www.uis.edu/emiquon/research


For additional information about the restoration of the Emiquon Preserve, contact Maria Lemke, The Nature Conservancy of Illinois: Email: mlemke@tnc.org Web: www.nature.org/emiquon


For additional information about real-time environmental monitoring systems, please contact YSI Environmental:


Tel: 800-897-4151

Email: environmental@ysi.com

Web: www.ysi.com







Summary of water quality data (average daily temperature, dissolved oxygen, and turbidity) collected from the YSI EcoNet system installed at the Emiquon Preserve pump station





Above: Maria Lemke (left) and team installing a monitoring station

At left: Bill Littleton, YSI Technical Support, setting up an EcoNet Data Acquisition System inside a monitoring station